
## MILLER SOIL BOXES



- Stainless steel current distribution plates and removable brass pins can be used with any 4-Terminal Resistance Meter, including Miller 400A, Miller 400D and Nilsson 400
- Can also be used with any M.C. Miller multimeter (or separate volts and amps meters) together with an external battery
- Can be used to satisfy the ASTM (G57 and G187) standards as well as the AASHTO (T-288) Standard

